

How to Set Up Fitbit Pay

To use contactless payments, add at least one credit or debit card from a participating bank to the Fitbit app. The Fitbit app is where you add and remove payment cards, set a default card for your tracker, edit a payment method, and review recent purchases.

- 1. From the Today tab in the Fitbit app, tap your profile picture, then tap the Charge 5 tile.
- 2. Tap the Wallet tile.
- 3. Follow the on-screen instructions to add a payment card. If you're adding a card for the first time, you might be prompted to set a **4-digit PIN code** for your tracker. Note that you also need passcode protection enabled for your phone.
- 4. After you add a card, follow the on-screen instructions to **turn on notifications for your phone** (if you haven't already done so) to complete the setup.

NOTE: You can add **up to 5 payment cards** to the Wallet and choose which card to set as the default payment option.

Fitbit Pay | Contactless Payments Technology